




RV WI-FI 5G

Quick start User Guide

1 Setting up the SIM card

a Activate and add data to your SIM card as per instructions on the sim card packet.




b Press the SIM OPEN button (below the sim card slot) to open the sim card slot.



c Remove the SIM card tray.

d Place your SIM card on a flat surface to make sure it is entirely flat.

e Insert your SIM card into the SIM card tray and make sure it is completely flat in the SIM card tray. There is a cut out to help align the two. If you do not have a full sized SIM card, use the adapter provided to make it a full size.



2 Setting up the Antenna's

Stick Antenna's OR 4 in 1 Antenna

Attach all eight antenna's to the antenna ports.
a 4 x small antenna's into the control panel on the side of the router. Marked 'Wi-Fi 2.4' & 'Wi-Fi 5.8'

Install the 4 in 1 antenna on the roof.
a 2 x small antenna's into control panel marked 'Wi-Fi 5.8'. Attach cables from 4 in 1 antenna marked 'Wi-Fi' into control panel marked 'Wi-Fi 2.4'.

b 4 x paddle antenna's into top and bottom of the router, marked '4G/5G'.

b 2 x paddle antenna's into base marked '4G/5G'. 2 x cables from 4 in 1 antenna marked '4G/5G' into top marked 'External 4G/5G'



3 Setting up the Power Cord

Plug the 12volt power socket into a single power socket. We also stock 240v to 12v converters if required.



4 Connecting to the WIFI

- With your activated and data applied SIM inserted, power on the router and wait 5 minutes.
- On your device (phone/laptop etc.), go to : SETTINGS.
- Go to: WIFI. You will notice on some occasions, RV WIFI will come up twice. RV WIFI 5.8 abc123 and RV WIFI abc123.
- Choose RV WIFI 5.8 abc123 when available. It is faster, but has less range.
- Click on: RV WIFI 5.8 abc123 (when available), if not click on RV WIFI abc123
- You will be asked for a WIFI Password or Security Key. Type in: rvwifi1234 (all lower case and no spaces).
- Click on: connect.
- Wait for confirmation of connection.
- Scan the QR code on the front of the router for full instructions and to change your WIFI password.